



# POOL HEATER

## Troubleshooting Guide for Pool Heaters

Here is a Troubleshooting Guide and instruction manual which should resolve all issues and error codes experienced with the Bestway Pool Heater.

### **E01 ERROR CODE**

#### **WATER FLOW ISSUE**

##### **REASON** WATER FLOW ISSUE

This error code is visible if there is an issue with the water flow sensors in the pool heater.

#### **WATER FLOW ISSUE**

##### **SOLUTIONS** WATER FLOW ISSUE – HOW TO RESOLVE THIS

Water flow sensor on the heater has broken.

This error code can be become visible if there is an issue with the water flow through either the filter pump or sand filter used on the spa.

Please do not attempt to open or replace any internal parts on the heater.

Heater pump set up incorrectly

The heater is set up in the following order:

- \* Hose from “A” to the pool heater
- \* The arrow on the heater is facing the filter pump
- \* Hose goes from heater into filter pump
- \* Hose from filter pump goes into “B”

Please note this is set up incorrectly in the pool manual

### **E02 ERROR CODE**

#### **WATER TEMPERATURE**

##### **REASON** WATER TEMPERATURE

This error code is visible if there is an issue with the temperature of the water. This will become visible if the water or ambient temperature drops below 4°C.

#### **WATER TEMPERATURE**

##### **SOLUTIONS** WATER TEMPERATURE – HOW TO RESOLVE THIS

The heater is not designed to operate below 4°C.

Please disconnect / unplug the pool heater.

Place this in a warm environment to allow the internal parts to warm up.

Once warm, place the heater back on the pool ensuring the water is above 6°C.

## **E03 ERROR CODE**

### **WATER TEMPERATURE**

#### **REASON** WATER TEMPERATURE

This error code is visible if there is an issue with the temperature of the water. This will become visible if the water or ambient temperature reaches above 50°C.

### **WATER FLOW ISSUE**

#### **SOLUTIONS** WATER TEMPERATURE – HOW TO RESOLVE THIS

The heater is not designed to operate above 50°C.

Please disconnect / unplug the pool heater.

Place this in a cool environment, out of direct sunlight to allow the internal parts to cool down.

Once cool, place the heater back on the pool ensuring the water is below 38°C.

## **E04 ERROR CODE**

### **WATER SENSOR ISSUE**

#### **REASON** WATER SENSOR

This error code is visible if there is an issue with the water flow sensors in the pool heater.

### **WATER SENSOR ISSUE**

#### **SOLUTIONS** WATER SENSOR – HOW TO RESOLVE THIS

As this error code is visible once there is an issue with the internal parts, there are no known steps to resolve this.

Please do not attempt to open up the pool heater and resolve the issue.

Please contact Bestway Swimming Pools regarding this.

## **E05 ERROR CODE**

### **MANUAL RESET REQUIRED**

#### **REASON** POOL HEATER RESET

This error code is visible if there is an issue with the pool heater and this requires to be reset. The manual reset thermal cut-out has been tripped.

### **MANUAL RESET REQUIRED**

#### **SOLUTIONS** POOL HEATER RESET REQUIRED– HOW TO RESOLVE THIS

This error code is visible once the pool heater is required for reset.

Push the reset button on the pool heater. Please find a photo below for the reset button on the pool heater.

If the alarm is still visible, check the RESET BUTTON section on the manual below.

If this does not resolve the issue, please contact Bestway Swimming Pools.

## **E06 ERROR CODE**

### **FUSE ISSUE**

#### **REASON** POOL HEATER RESET

This error code is visible if there is an issue with the pool heater power supply and fuse issue.

## **MANUAL RESET REQUIRED**

### **SOLUTIONS** POOL HEATER RESET REQUIRED– HOW TO RESOLVE THIS

This error code is visible if there is an issue with the fuse within the pool heater.  
Please do not attempt to open up the pool heater, change the fuse or aim to resolve the issue.  
Please contact Bestway Swimming Pools regarding this due the issue.

## **FURTHER TROUBLESHOOTING**

### **HEATING LIGHT DOES NOT WORK**

**REASON** POWER FAILURE

**SOLUTIONS** Check the power supply (ensure no extension cables or multi-sockets are being used).

### **POOL HEATER DOES NOT HEAT CORRECTLY**

**REASON** HEATING TIME IS TOO LONG

**SOLUTIONS** Check the LED light on the pool heater is working. Always use a pool cover

**REASON** FILTER PUMP OR SAND PUMP DOES NOT MATCH THE HEATER

**SOLUTIONS** Replace the filter pump/ Sand filter following the manual.

**REASON** POOL HEATER SET-UP FAILED

**SOLUTIONS** Reset the pool heater after each initial set up.

**REASON** THERMAL CUT OUT CUT OFF

**SOLUTIONS** Press the “Reset” button on the pool heater

### **INLET AND OUTLET VALVES LEAK WATER**

**REASON** THE HOSE CLAMPS ARE LOOSE

**SOLUTIONS** Ensure the hose clamps are tight

**REASON** HOSE O-RING NOT IN THE CORRECT POSITION

**SOLUTIONS** Check the hose O-Rings are not damaged or split

**REASON** HOSE HAS BROKEN

**SOLUTIONS** Hoses between the filter pump and heater need replacing

### **WATER DOES NOT FLOW**

**REASON** FILTER / SAND PUMP DOES NOT WORK

**SOLUTIONS** A. Reset the filter pump / sand filter according to the set up instructions. Check the filter or sand pump is working accordingly.

## **THE HEATER LIGHT TURNS OFF BUT THE HEATER WORKS**

**REASON** THE LIGHT ON THE HEATER HAS BROKEN

**SOLUTIONS** Check the power supply to the pool heater

### **OTHER POSSIBILITIES**

- Ensure the pool heater is plugged directly into the mains and not through an extension cable.
- Do not place the pool heater in direct sunlight for long periods of time.
- Never use the pool within winter or heavy rain.